

# OZCO Project #211 - Pavilion Post and Beam Shade Structure -Attached to House









### **Overview**








## **Translucent**








ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	56629	OWT Timber Screw 7-1/2"
2	4	56609	8x8 Post Base (8x8-PB-LS)
3	1	56619	Truss Base Fan
	3	56611	Truss Accent (TA-LS)
	1	56625	OWT Timber Screw 1-3/4"
4	2	56652	OWT Timber Bolt 10-12"
5	2	56651	OWT Timber Bolt 8-10"
6	2	8x8 Cedar Post	8x8x8'0"
7	3	4x10 Cedar Board	4x10x12'0"
8	2	8x8 Cedar Post 4x6 Cedar	8x8x8'0"
9	1	4x6 Cedar Board 4x6 Cedar	4x6x4'0"
10	2	Board	4x6x2'7"
11	2	4x6 Cedar   Board	4x6x8'0"
12	1	2x6 Cedar Board	2x6x12'0"
13	2	2x6 Cedar Board	2x6x16'0"
14	16	2x4 Cedar Board	2x4x8'0"
15	26	2x4 Cedar Board	2x4x16'0"
16	6	4x4 Cedar Post	4x4x42

### **Bill of Materials**






QTY.	PART NUMBER	DESCRIPTION
4	56609	8x8 Post Base (8x8-PB-LS)
1	56619	Truss Base Fan 8:12
3	56611	Truss Accent (TA-LS)
1	56625	OWI Timber Screw 1-3/4"
2	56652	OWT Timber Bolt 10-12"
2	56651	OWI Timber Bolt 8-10"
1	56629	OWT Timber Screw 7-1/2"
4	8x8x8L	8x8x8
3	4x4x8L	4x4x8
3	4x10x12L	4x10x12
1	4x6x10L	4x6x10
2	4x6x8L	4x6x8
1	2x6x12L	2x6x12
2	2x6x16L	2x6x16
16	2x4x8L	2x4x8
26	2x4x16L	2x4x16



**OZCO** 

# Laredo Sunset & Ironwood




Laredo Sunset (566XX series)

2 great styles

Same functionality

choose your connection lifestyle

both styles available for most products




Ironwood (517XX series)











OZCO Project #211 - Pavilion Post and Beam Shade Structure – Attached to House


V2.00 - Installation Instructions, Specifications and Project Plans are effective 2/15/2017 . This information is updated periodically and should not be relied upon after 2 years from 2/15/2017 . Please visit OZCOBP.com to get current information.




















#### **Cutlist**















# Post Base installation (cropped top view)










step 3














repeat steps 6 & 7 on opposite side-










step 11







# lan's Concept




**lan's Concept** 

V2.00 - Installation Instructions, Specifications and Project Plans are effective 6/14/2017 . This information is updated periodically and should not be relied upon after 2 years from 6/14/2017 . Please visit OZCOBP.com to get current information.

OTCO BUILDING PRODUCTS




























mark ledge location


multiple cuts
approximately 1/4"
apart to mark





remove pieces





set saw cut depth; start cuts 1/4" from top

## **Dato cut details**