

tehkTM

style matters

www.tehk.com



1. Pre-cut the top and bottom rails. Working outward from the center of each rail, use a pencil to mark connector locations at required spacing.



2. Secure a connector at each mark using the screws provided.



3. Secure the bottom rail to the deck posts, then slide a baluster onto each connector. Attach the top rail and secure it to the deck posts.